

# How to upgrade to HikCentral Professional v1.7.1

### **Legal Information**

©2020 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

#### About this Manual

The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website

#### (https://www.hikvision.com/).

Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

#### Trademarks

**HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.

Other trademarks and logos mentioned are the properties of their respective owners.

#### Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

YOU ACKNOWLEDGE THAT THE NATURE OF INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

# **Symbol Conventions**

The symbols that may be found in this document are defined as follows.

Symbol	Description	
Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.	
Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.	
iNote	Provides additional information to emphasize or supplement important points of the main text.	

### Contents

Chapter 1 Introduction	1
Chapter 2 Flow Chart	2
Chapter 3 Save Your Activation Code	3
Chapter 4 System Backup	4
Chapter 5 Get Installation Package	7
Chapter 6 Install Package	8
Chapter 7 Reactive Your System	9
7.1 Activate License - Online	9
7.2 Activate License - Offline	10

# **Chapter 1 Introduction**

When the new version of HikCentral Professional is released, you can upgrade your HikCentral Professional to the latest version with the installation package.

### Caution

After upgrading with the installation package, you need to activate your software again with the original Licenses you purchased. As a result, please make sure you have properly saved your License information (activation codes) before starting.

# **Chapter 2 Flow Chart**





# **Chapter 3 Activation Code Backup**


Since after upgrading your HikCentral Professional with the latest installation package, your HikCentral Professional will be deactivated automatically, you need to activate it again with your original activation code purchased before.

As a result, you MUST properly keep your activation codes and make sure they are available after upgrading.

### **Chapter 4 System Backup**

Before starting the upgrade, it is recommended to back the system.

- To back up the system you will need to log in to the Web Client with an administrator account.
  - 1. On the HikCentral Web Client, click "Back Up and Restore System Data".





2. Select all the data types to back up and click "Back Up Now".


Back Up and F	Restore System Data			×
Back Up	Restore			
	Туре	<ul> <li>Configured Data</li> <li>Configured Pictures</li> <li>Received Events</li> <li>Received Alarms</li> <li>Face Comparison Data</li> <li>Card Swiping Records</li> <li>Attendance Records</li> <li>Vehicle Passing Records</li> <li>Video Analysis Data</li> <li>Server Logs</li> </ul>		
	* How Often	Monthly	-	
	* Which Day	1	•	
	* When	0:00	•	
	<b>•</b> • •			•
			Save	Cancel

Figure 4-2

Back Up and Restore System Data		×
Back Up Restore		
	Face Comparison Data	
	Card Swiping Records	
	Attendance Records	
	Vehicle Passing Records	
	Video Analysis Data	
	✓ Server Logs	
* How Often	Monthly -	
* Which Day	1 •	
* When	0:00 🗸	
() Save to	C:\Program Files (x86)\HikCentral\VSM Servers\VSM\Backup	
* Max. Number of Backups	3	
	Back Up Now	Ŧ
	Save	Cancel



- 3. After the backup process is finished, go to the path in the picture above and **copy the folder to a safe location.**
- 4. For HikCentral deployments using access control, Person information will need to be exported manually. Export the Person information on the **Web Client Person Person List**.



#### Figure 4-4

For more information, please refer to the user manual

5. Open the HikCentral Service Manager and stop all services, then close it.

					– ×
	Servic	ice Name	Port No	Status	Operation
Service Manager	$\sim$	HikCentral Video Surveillance Mana	15300;14200	Stopped	<b>D</b> 5
HikCentral		3rd Party Device Access Ga		Stopped	<b>D</b> 5
		HikCentral Management Se	80;443	Stopped	<b>5</b>
😑 Stop All		HikCentral Streaming Gate	554;10001;559	Stopped	<b>5</b>
C Stop Air		Keyboard Proxy Service	8910	Stopped	<b>D</b> 5
🏷 Restart All		Smart Wall Management Service		Stopped	<b>D</b> 5
0 Day(s) 01:45:41 Run Time					
				🗸 — Auto-Laun	ch

Figure 4-5

- 6. Go to the HikCentral installation path **\HikCentral\VSM Servers\PostgreSQL** and make a copy the **"data"** folder to another safe path.
- 7. Run the HikCentral Service Manager and make sure the services are back running.

# **Chapter 5 Get Installation Package**

You can get the latest installation package from here.

### **Chapter 6 Install Package**

Install the latest installation package on the HikCentral server to upgrade to the latest version. The system's activated licenses will be cleared after upgrading. Please save your licenses before installation.

- 1. Copy the installation package to the server running the HikCentral Professional service.
- 2. Run the installation package as an administrator.
- 3. Follow the instructions of the installer to upgrade the server.

While running the installer a prompt may appear "close the beeagent.exe" which is referring to HikCentral Services Manager "HikCentral Watch Dog" as seen in figure 6-1.

	HikCentral Professional - InstallShield Wizard	x
	Welcome to the InstallShield Wizard for HikCentral Professional The InstallShield Wizard will update the installed ver	
	HikCentral Professional - InstallShield Wizard	То
2	The BeeAgentGUI.exe is running. Exit the program first.	
	ОК	
	< Back Next > C	ancel

Figure 6-1 Installer Message

# **Chapter 7 Reactivate System**

After upgrading your software to the latest version with the latest installation package, you need to activate your HikCentral Professional again with your original license (activation codes). After activation, your system will recover to normal status.

We provide online activation and offline activation and you can choose according to the network status of your SYS server.

### 7.1 Activate License - Online

For HikCentral servers with internet access, the server can be activated in online mode.

#### Steps

- 1. Log in to HikCentral Professional via the Web Client.
- 2. Click **Online Activation** in the License area to open the License configuration window.




Figure 7-1 Online Activation

3. Enter the activation code.

### **i**Note

- ullet If you have purchased more than one license, you can click  $\,+\,$  and enter other activation codes.
- A maximum of 110 licenses are allowed in one system.
- 4. Optional: Set the **Hot Spare** switch to **ON** and input the required parameters if you want to build a hot spare system.

#### **i**Note

- You must select Hot Spare mode when you install the system.
- For how to build the hot spare system, please contact our technical support engineers.
- 5. Click **OK** and the License Agreement dialog opens.

- 6. Read the License Agreement.
  - If you accept the terms of the License Agreement, check I accept the terms of the agreement and click OK to continue.
  - If you do not accept the agreement, click **Cancel** to cancel the activation.
  - The activation will start.

### 7.2 Activate License - Offline

For HikCentral servers with no internet access, the server must be activated in offline mode.

#### Steps

- 1. Log in to HikCentral Professional via the Web Client.
- 2. Click Export the license request file in the License area.



Figure 7-2 Export Request File

3. Enter the activation code.

### **i**Note

- If you have purchased more than one License, you can click  $\,+\,$  and enter other activation codes.
- A maximum of 110 licenses are allowed in one system.




Figure 7-3 Export File

4. Optional: Check **Hot Spare** and enter the required parameters if you want to build a hot spare system.

### iNote

- The switch will be displayed if you select **Hot Spare** mode when installing the system.
- For how to build the hot spare system, please contact Hikvision's technical support engineers.

#### 5. Click Export.

6. In the pop-up License Agreement window, check I accept the terms of the agreement and click OK.

A request file named "ActivationRequestFile.bin" will be downloaded. Save the file to the correct directory or the removable storage medium (e.g., USB flash disk).

- 7. Copy the request file to a machine with internet access for activation.
- 8. On the machine with internet access, enter the following website:

#### https://license.hikvision.com:8443/#/active.

9. Scroll down and Click Browse and then select the request file downloaded in Step 6.

"Import." A notification with the text "Activated" will appear on your screen.
As Step 4 instructs, click on "Browse" as shown below to open your local directory, and then choose the ActivationRequestFile.bin and click "Submit" to upload the Request File.
Browse

Figure 7-4 Select Request File

#### 10. Click Submit.

A response file named "ActivationResponseFile.bin" will be downloaded. Save the response file to the proper directory or the removable storage medium (e.g., USB flash disk).

- 11. Copy the response file to a machine with access to the HikCentral Professional's Web Client.
- 12. In the License area, click Import the activation file.

License
License Details
Online Activation (network available) Offline Activation (network not available) Step 1:Export the license request file
Step 2:Import the activation file

Figure 7-5 Import Respond File

- 13. Click \_\_\_\_ and select the response file downloaded in Step 10.
- 14. Click Import.

